User Manual—IOT Geiger Counter ESP32-OLED

Index:

Part 1: Instruction

Part 2: Using ThingSpeak cloud server

Part 3: Using IFTTT sending message

connecting Geiger Counter and Server and smartphone

Appendix

Part 1: Instruction

You need to setup one WiFi hotspot using your smartphone or wireless router

Using name: huawei153, password:11341136(or you could change wifi SSID and password on Arduino Code)

- 2) Power on with power cable to any 5V. MicroUSB to USB-A male.
- 3) OLED will display: Welcome Measuring

Then show Nuclear radiation dose CPM: counter Per Minute


For J305 geiger tube, rough calculation could be 151CPM=1 usv/h(Micro Sievert per hour).

(You can also re-write code to improve algorithm for better measuring result of Nuclear radiation)



RiZhao

Part 2:
Using ThingSpeak to upload data to server




2.1 register one channel


Open: https://thingspeak.com

Register one user using your email

 $Channels {\longrightarrow} New\ Channels {\longrightarrow} Fields \quad Radioactivity {\longrightarrow} Save\ Channel$

API Keys->copy Write API Key





```
Copy the WriteAPIKey in code:

const char * myWriteAPIKey = "BGOHM1CIYHUROM70"; //update

Using your wifi user and password in the code:

// WLAN

#define mySSID "huawei153" //your wifi user name

#define myPASSWORD "11341136" //your wifi password

Click upload:
```





Part 3:

Using IFTTT for alarming


 $IFTTT \ \ means \ \ if \ \ this \ \ then \ \ that$

functional block diagram:





Finally, we get alarming when Nuclear radiation is over one value, and you smartphone could get message.



Appendix:

Tech. email: cajoetech@qq.com

Development board are all tested before shipping.